

# Installation instructions

# SAFETY AND PROPER USAGE

To ensure safe and enduring performance of this product, you must comply strictly with the instructions enclosed herein. Non-compliance with instructions or improper handling of the product will void your warranty! Usage of this product in conditions not specified in this manual or in contrary to the instructions hereby provided is considered IMPROPER. The manufacturer will not be held liable for any damages resulting from improper use of the product.

### **SAFETY & WARNING INSTRUCTIONS**

- Observe valid and generally accepted safety rules when planning, installing and using this product.
- Take proper measures to prevent unintentional operation of the product or damage to it.
- Do not attempt to disassemble this product or lines in the system while they are under pressure.
- Always depressurise the compressed air system before working on the system.

It is important that personnel use safe working practices and observe all regulations and legal requirements for safety when operating this product. When handling, operating or carrying out maintenance on this product, personnel must employ safe engineering practices and observe all local health & safety requirements & regulations. International users refer to regulations that prevail within the country of installation. Most accidents, which occur during the operation and maintenance of machinery, are the result of failure to observe basic safety rules or precautions. An accident can often be avoided by recognising a situation that is potentially dangerous. Improper operation or maintenance of this product could be dangerous and result in an accident causing injury or death. The manufacturer cannot anticipate every possible circumstance, which may represent a potential hazard. The WARNINGS in this manual cover the most common potential hazards and are therefore not all-inclusive. If the user employs an operating procedure, an item of equipment or a method of working which is not specifically recommended by the manufacturer he must ensure that the product will not be damaged or made unsafe and that there is no risk to persons or property.

# INSTALLATION INSTRUCTIONS

Before installing the TEC-44, make sure it complies with your request and that it suits your application!

1. Unpack the TEC-44 and visually inspect for any transport damage incurred after leaving our factory.

2. Depressurise the system before installation or maintenance is carried out!

3. Locate a suitable condensate draining point in your compressed air system to connect your TEC-44.

- Connect the outlet to an oil/water separator.

4. After double checking that the power supply corresponds with the voltage specified on your TEC-44, you can switch it ON.

5. The TEC-44 will start up in program 4 (see chart 1, page 6). Any changes to the program selection will be stored. Refer to step 6 and 7 for program selections.

#### 6. CHANGING THE INTERVAL TIME CYCLE.

Should the pre-set interval time cycle (4) not be suitable for your requirements, alternative interval times can be selected.

Refer to chart 1 (page 6) and select the program best suited to your requirements.

Follow the procedure below to change the program:

a. Choose the preferred program (0 - 9 or -).

b. Press [SET] until your program number is displayed.

#### 7. CHANGING THE ROTATION TIME CYCLE.

Should the pre-set rotation time cycle (A) not be suitable for your requirements, alternative rotation times can be selected.

Refer to chart 2 (page 6) and select the program best suited to your requirements.

Follow the procedure below to change the program:

a. Press [SET] and [TEST] simultaneously.

b. Press [SET] to select required time.

c. Press [TEST] to confirm selection.

d. The TEC-44 is now programmed to your desired program settings and will work fully automatically.

8. Slowly pressurise the system.

9. Your TEC-44 is ready for operation!





INTERVAL TIM	ITERVAL TIME (OFF)		
CHART 1	Program	Valve closed	
	0	4 min	
	1	8 min	
	2	15 min	
	3	30 min	
	4	1 hrs	
	5	2 hrs	
	6	4 hrs	
	7	8 hrs	
	8	16 hrs	
	9	24 hrs	
	-	External Switching (see page 8, adding a remote switch)	

ROTATION TIME CYCLE (ON)					
CHART 2	Program	Valve open			
	Α	7 seconds rotation (non-stop)			
	В	10 seconds rotation (valve stays open	3 s)		
	С	15 seconds rotation (valve stays open	8 s)		
	D	20 seconds rotation (valve stays open	13 s)		
	E	25 seconds rotation (valve stays open	18 s)		
	F	30 seconds rotation (valve stays open	23 s)		
	н	45 seconds rotation (valve stays open	38 s)		
	L	1 minute rotation (valve stays open	53 s)		
	Р	5 minutes rotation (valve stays open	4m 53 s)		
	0	15 minutes rotation (valve stays open	14m 53 s)		
	Note: Wher	n the valve is OPEN, the valve ind	icator is RED		

## **BATTERY BACKUP**

The TEC-44 is equipped with a Power Failure Protection Safeguard. The battery back-up is intended to finish a rotation cycle in case of a power failure. The Power Failure Protection Safeguard consists of 4 AA size, 1.5V (penlight) batteries.

1. To (re)place the batteries, open the housing by unscrewing the 4 housing screws.



2. Place the 4 batteries and close the housing by replacing the 4 housing screws.



Rely as little as possible on the power failure protection safeguard. Solve the power supply problem as soon as possible!

# ADDITIONAL OPTIONS (1/2)



# ADDITIONAL OPTIONS (2/2)

VOLTAGE SWITCH

The TEC-44 can be converted to suit 115VAC or 230VAC electrical systems. Use the below mentioned diagrams to configure your drain to the corresponding electrical power supply.



## **TECHNICAL SPECIFICATIONS**

Maximum compressor capacity	Any size		
Pressure range	0 - 40 bar	0 – 600 psi	
Supply voltage options	24VDC, 115VAC and 230VAC 50/60Hz.	(depending on model!)	
Medium temperature	1 - 60 °C	34 – 140 °F	
Ambient temperature	1 - 55 °C	34 – 131 °F	
Timer cycle range (ON / OFF)	7 seconds to 15 minutes ON / 4 minutes to 24 hours OFF		
Actuator pcb	SMT technology, ensuring consistency in production		
Timer cycle indication	Bright LED illumination, LED program indicator		
Test feature	Yes		
Valve type	2/2 way, motorised ball valve		
Valve orifice	12 mm	0.5″	
Valve seals	FPM and Teflon		
Inlet/outlet connections	1/2" (BSP or NPT)		
Inlet connection height	1.0 cm	0.04"	
Serviceable valve	Yes		
Valve housing material	Brass nickel plated, Stainless steel available		
Power connection	Cable and plug		
Environmental protection	IP65 (NEMA4)		
Remote switch option	Yes		
Valve position indicator	Yes, Red = OPEN		

#### SERVICE CHART

Date	Description	Name

# **DIMENSIONS (mm)**

