SAFETY AND PROPER USAGE

SAFE! IT AND PROPER USAGE
To ensure safe and enduring performance of this product, you must comply strictly with the instructions enclosed herein.

Non-compliance with instructions or improper handling of the product will void your warranty! Usage of this product in conditions not specified in this manual or in contrary to the instructions hereby provided is considered IMPROPER. The manufacturer will not be held liable for any damages resulting from improper use of the product.

SAFETY & WARNING INSTRUCTIONS

SAFETY & WARNING INSTRUCTIONS

Observe valid and generally accepted safety rules when planning, installing and using this product.

Take proper measures to prevent unintentional operation of the product or damage to it.


Do not attempt to disassemble this product or lines in the system while they are under pressure.

Always depressurize the compressed air system before working on the system. It is important that personnel use safe working practices and observe all regulations and legal requirements for safety when operating this product. When handling, operating or carrying out maintenance on this product, personnel must employ safe engineering practices and observe all local health & safety requirements & regulations. International users refer to regulations that prevail within the country of installation. Most accidents, which occur during the operation and maintenance of machinery, are the result of failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing a situation that is potentially dangerous. Improper operation or maintenance of this product could be dangerous and result in an accident causing injury or death. The manufacturer cannot anticipate every possible circumstance, which may represent a potential hazard. The WARNINGS in this manual cover the most common potential hazards and are therefore not all-inclusive. If the user employs an operating procedure, an item of equipment or a method of working which is not specifically recommended by the manufacturer he must ensure that the product will not be damaged or made unsafe and that there is no risk to persons or property.

NEVER CHANGE ORIGINAL COMPONENTS WITH ALTERNATIVES

NEVER CHANGE ORIGINAL COMPONENTS WITH ALTERNATIVES


MARNING This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and/or birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov



TECHNICAL SPECIFICATIONS

Maximum filter capacity	3500 CFM	
Maximum drainage capacity U3/U4 Version	31 gallons per hour at 230 psi (16 bar) 120 litres per hour at 230 psi (16 bar)	
Voltage options	230VAC / 115VAC / 24VAC / 24VDC	
Pressure range	0 – 50 bar	0 – 725 psi
Medium temperature	1-50°C	34 – 122 °F
Ambient temperature	1 – 50 °C	34 – 122 °F
Valve type	2/2 way, direct acting	
Valve orifice	1.8 mm	
Valve seals	FPM	
Inlet connection	1/2" (BSP or NPT), 3 inlet options	
Outlet connection	1/4" with hose connector	
Power connector	DIN 43650-B	
Inlet height	4.5" (top) and 2.9" & 0.6" (side)	
Test feature	Yes	
Serviceable valve	Yes	
Integrated mesh strainer	Yes	
Housing material	Corrosion resistant aluminium, EP coating	
Environmental protection	IP65 (NEMA4)	
Alarm feature type	U1 = Normally open contacts, closed when in alarm phase. LED on the	
Contact output switch (voltage free)	drain is OFF when in operation and ON when in alarm mode.	
	U2 = Normally closed contacts, open when in alarm phase. LED on the	
	drain is OFF when in operation and ON when in alarm mode.	
Alarm feature specification	Max. 230VAC, max 4A, 1000VA or 200VDC, 100W and min 5VDC, 100mA	

EXPLODED VIEW







3623 H1 & H2

INSTALLATION INSTRUCTIONS


Before installing this product, make sure it complies with your request and that it suits your application!

- 1.1 Unpack the unit and visually inspect for any transport damage incurred after leaving our factory
- 1.2 Depressurise the system before installation or maintenance is carried out!
- 1.3 We strongly suggest to use the supplied wall mounting bracket to avoid damaging the unit by strong vibrations. Fix the mounting bracket against a wall or structure before installing the drain. Use the supplied screws and plugs.
- 1.4 Use the four mounting screws to secure the drain to the mounting bracket
- 1.5(a) Top inlet connection: If you choose to use the top inlet, locate a suitable condensate draining point in your compressed air system and connect your drain as illustrated. Connect the outlet to a condensate cleaner. -The use of a ball valve is advisable. -We strongly recommend to use flexible tubing to avoid damaging the unit by strong vibrations caused by the compressor.
- 1.5(b) Side inlet connection: If you choose to use the side inlet, locate a suitable condensate draining point in your compressed air system and connect your drain as illustrated. Connect the outlet to an oil/water-separator.

 -The use of a ball valve is advisable. -The use of a venting line may be required. -We strongly recommend to use flexible tubing to avoid damaging the unit by strong vibrations caused by the compressor.
- 1.6 Unscrew the connector screw and remove the cap from the connector to connect your power cable as illustrated. Replace the power connector and tighten the connector screw (max. torque 0,3 Nm). -Make sure the gaskets are placed and secured properly to ensure IP65(NEMA4) rating. If your drain is pre-wired, go to step 1.7.
- 1.7 Slowly open the ball valve to restore normal system pressure and turn on the power supply
- 1.8 Press and hold down the TEST button to check the valve function. -A purging sound must be heard 1.9 Your drain is ready for operation! Note: We advise to check this product at least once a year and replace

serviceable parts when necessary. Note: Clean the strainer periodically to avoid possible blocking causes by rust and/or debris. Note: Check the valve function periodically by pressing the TEST button. A purging sound must be

DIMENSIONS (inches)




REPLACEMENT PARTS

Description	Part No.
1. Service kit	34000 HP

MAINTENANCE INSTRUCTIONS

These instructions are for cleaning the drain. If your drain requires servicing, i.e. replacement of wearing components, please refer to our dedicated service instructions (supplied with the service kit).



- 2.1 Stop the condensate supply, i.e. close the ball valve which is installed in front of the drain.
 2.2 Press the TEST button to empty the drain of any residual condensate and to depressurise the drain.
- 2.3 Switch off the power supply and remove the power connector by unscrewing the connector screw. Make sure the display is off to check if the power supply is successfully disconnected.
- 2.4 Open the housing by unscrewing the four housing bolts using a 5mm Allen key and remove the top part from the reservoir.
- 2.5 Slide the electronics compartment up and unscrew the valve from the bottom part of the housing using a 23mm wrench WARNING: make sure the electronics compartment does not get wet, this will damage the unit!
- 2.6 Clean all valve parts thoroughly. Make sure there's no debris left in the other parts of the drain
- 2.7 Use a 10mm Allen key to remove the plug and strainer. Clean the strainer thoroughly. Replace the strainer and plug, using a 10mm Allen key.
- 2.8 Reassemble the valve inner parts and screw the valve back in to the bottom part of the housing, using a 23mm wrench (max. torque 10 Nm).
- 2.9 Close the housing by replacing the electronics compartment and top part on the reservoir and fixing the 4 housing bolts (max. torque 10 Nm).


Make sure the gaskets are secured properly to ensure IP65(NEMA4) rating and make sure the electronics have not been in contact with water.

WARNING: make sure the cable connected to the electronics compartment does not get damaged while re-assembling the components!

2.10 Replace the power connector, tighten the connector screw (max. torque 0,3 Nm) and turn on the power supply. Make sure the gasket is secured properly to ensure IP65(NEMA4) rating. ${\it Make sure the display lights up to check if the power supply is successfully connected.}$


2.11 Slowly open the ball valve to restore the condensate supply.

2.12 Press and hold down the TEST button to check the valve function. Your drain is ready for operation! Check the drain periodically by pressing the TEST knob. A purging sound must be heard.




ALARM INSTALLATION INSTRUCTIONS

The drain is equipped with an alarm feature. The alarm feature can be connected to an external alarm device with its own power supply.




2. Connect the cable to your alarm device, any device of your choice can be applied i.e. a (flashing) light or alarm panel.



1. Unscrew the connector screw and remove the cap from the alarm connector to connect the alarm cables to the connector as shown below. Caution is required as you may be working with hazardous voltages!



3. Connect your alarm device to a power supply. The alarm switch type is a 'contact output switch'. An external power supply is required as the alarm connection point on the drain works like a relay switch only



4. Connect the power supply to the drain alarm connector to close the circle. Replace the connector and tighten the connector screw (max. torque 0,3 Nm). Make sure the gasket is secured properly to ensure IP65(NEMA4) rating.



