SAFETY AND PROPER USAGE

SAFE! I AND PROPER USAGE
To ensure safe and enduring performance of this product, you must comply strictly with the instructions enclosed herein.

Non-compliance with instructions or improper handling of the product will void your warranty! Usage of this product in
conditions not specified in this manual or in contrary to the instructions hereby provided is considered IMPROPER. The
manufacturer will not be held liable for any damages resulting from improper use of the product.

SAFETY & WARNING INSTRUCTIONS

SAFETY & WARNING INSTRUCTIONS

Observe valid and generally accepted safety rules when planning, installing and using this product.


Take proper measures to prevent unintentional operation of the product or damage to it.

Do not attempt to disassemble this product or lines in the system while they are under pressure.

Always depressurize the compressed air system before working on the system. It is important that personnel use safe working practices and observe all regulations and legal requirements for safety when operating this product. When handling, operating or carrying out maintenance on this product, personnel must employ safe engineering practices and observe all local health & safety requirements & regulations. International users refer to regulations that prevail within the country of installation. Nost accidents, which occur during the operation and maintenance of machinery, are the result of failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing a situation that is potentially dangerous. Improper operation or maintenance of this product could be dangerous and result in an accident causing injury or death. The manufacturer cannot anticipate every possible circumstance, which may represent a potential hazard. The WARNINGS in this manual cover the most common potential hazard. The WARNINGS in this manual cover the most common potential hazards and are therefore not all-inclusive. If the user employs an operating procedure, an item of equipment or a method of working which is not specifically recommended by the manufacturer he must ensure that the product will not be damaged or made unsafe and that there is no risk to persons or property.


NEVER CHANGE ORIGINAL COMPONENTS WITH ALTERNATIVES

MARNING This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and/or birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov



TECHNICAL SPECIFICATIONS

	18 gallon version	59 gallon version
Dimensions	28x20,5x12,5 inch	48,5x32,5x16,5 inch
Color	Black	
Weight	Approx. 55 lbs	Approx. 77 lbs.
Max. moisture collection capacity	18 gallon	59 gallon
Max. capacity/distributed load	330 lbs	1100 lbs
Material	PE	
Grid	Galvanized steel	
Forklift slots	Pedestals	Sleds



INSTALLATION INSTRUCTIONS

Before installing this product, make sure it complies with your request and that it suits your application!

- 1. Unpack the unit and visually inspect for any transport damage incurred after leaving our factory.
- 2. Check the content of the box before continuing installation of this product.
- 3. Screw on the pedestals (or sleds) using a 13mm box spanner (or other suitable tool).
- 4. Install your Condensate Cleaner on top of the drip tray. Note: use the instruction manual that comes with your condensate cleaner for correct installation of your cleaner.

DIMENSIONS (inches)

